



## OBDII T-Bypass Short Installation (2019+ Ram 2500 & 3500)

1. Cut off the key tab on the green plug using snips or a knife.
2. Squeeze the tabs on the sides of the factory OBD2 connector and remove it from the factory bracket.
3. Plug the white connector into the block on the Ram that's closer to the driver door – it has a lot of plugs that have yellow wires, as shown.
4. Plug the green connector into the block on the Ram that's closer to the firewall – it has plugs that have white wires.
5. Plug the factory OBD2 into the Male OBD2 from the T-Harness.
6. Clip the OBD T-Harness female that only has black wires into the factory bracket. You will need to stretch the locking tabs outward first so they can lock into the bracket.
7. Tie all the wires up and out of the way. The OBD2 female that has the colored wires on the back is for the Tazer to plug into.

